



## INSIDE CORNERS

- Install a row of boards on the 1<sup>st</sup> wall tight against the wall (the inside corner).
  - Then start the 2<sup>nd</sup> wall starting flush against the boards from the 1<sup>st</sup> wall. Repeat.




NOTE: If the wall is not 90°, you may need to cut the boards at an angle (MITER) to get a tight fit.

## OUTSIDE CORNERS w/ return


### OPTION 1: CUT & BUTT

Install a row of boards on the 1<sup>st</sup> wall to the edge of that wall. Then start the 2<sup>nd</sup> wall, covering the cut edge of the last board on 1<sup>st</sup> wall. Make sure the first board has a 'factory colored edge'. Carry on and repeat.



### OPTION 2: ALTERNATING BUTTS


Install the first row as per OPTION 1 ABOVE. Start the 2<sup>nd</sup> row from the opposite wall and work in the opposite direction as the 1<sup>st</sup> row, again finishing with the last board at the edge of that wall. Then make sure the 'factory-colored edge' of opposing board covers the cut edge. Carry on and repeat.



### OPTION 3: 'MITERING'


Install a row of boards on the 1<sup>st</sup> wall. Measure the length of the final cut for the outside corner piece. Cut 45° angle on the board, and then measure from the inside of the board to properly cut the length of your missing corner piece. Then start the 2<sup>nd</sup> wall cutting the 1<sup>st</sup> board at a 45° angle & marrying to the other 45° angle. Carry on and repeat.

NOTE: you may want to use the same board on both sides of the miter to have a more 'continuous' look)



### OPTION 4: CREATE A TRIM

This is very easy. You can use a standard board, and simply place it vertical on both sides of the corner. Or you can 'rip' or cut a board in half lengthwise, and have a 2.5" board. Again, these can simply be butt together, or mitered.







## OUTSIDE CORNERS w/out return

### OPTION 1: FINISHED ENDS

Install a row of boards on the 1<sup>st</sup> wall to the edge of that wall.  
Make sure the final board has a 'factory colored edge'. Carry on and repeat.



### OPTION 2: CREATE A SINGLE TRIM

This is very easy. You can use a standard board, and simply place it vertical on one side of the corner. Or you can 'rip' or cut a board in half lengthwise, and have a 2.5" board.

### OPTION 3: CREATE A DOUBLE TRIM

Again, this is very easy. You can use a standard board, and simply place it vertical on both sides of the corner. Or you can 'rip' or cut a board in half lengthwise, and have a 2.5" board.

Again, these can simply be butt together, or mitered.

